


---

# INSTALLATION INSTRUCTIONS

---



---

**Small Swivel Table Stand**

---

## DISCLAIMER

Milestone AV Technologies and its affiliated corporations and subsidiaries (collectively "Milestone"), intend to make this manual accurate and complete. However, Milestone makes no claim that the information contained herein covers all details, conditions or variations, nor does it provide for every possible contingency in connection with the installation or use of this product. The information contained in this document is subject to change without notice or obligation of any kind. Milestone makes no representation of warranty, expressed or implied, regarding the information contained herein. Milestone assumes no responsibility for accuracy, completeness or sufficiency of the information contained in this document.

Chief® is a registered trademark of Milestone AV Technologies. All rights reserved.

## ! IMPORTANT WARNINGS AND CAUTIONS!

**! WARNING:** A WARNING alerts you to the possibility of serious injury or death if you do not follow the instructions.


**! CAUTION:** A CAUTION alerts you to the possibility of damage or destruction of equipment if you do not follow the corresponding instructions.

**! WARNING:** Failure to read, thoroughly understand, and follow all instructions can result in serious personal injury, damage to equipment, or voiding of factory warranty! It is the installer's responsibility to make sure all components are properly assembled and installed using the instructions provided.













**! WARNING:** Failure to provide adequate structural strength for this component can result in serious personal injury or damage to equipment! It is the installer's responsibility to make sure the structure to which this component is attached can support five times the combined weight of all equipment. Reinforce the structure as required before installing the component.

**! WARNING:** Exceeding the weight capacity can result in serious personal injury or damage to equipment! It is the installer's responsibility to make sure the combined weight of all components attached to the STS1 up to (and including) the display does not exceed 30 lbs (13.6 kg). Use with products heavier than the maximum weight indicated may result in collapse of the mount and its accessories causing possible injury.


## DIMENSIONS




**LEGEND**

	<b>Tighten Fastener</b> Apretar elemento de fijación Befestigungsteil festziehen Apertar fixador Serrare il fissaggio Bevestiging vastdraaien Serrez les fixations		<b>Pencil Mark</b> Marcar con lápiz Stiftmarkierung Marcar com lápis Segno a matita Potloodmerkteken Marquage au crayon
	<b>Loosen Fastener</b> Aflojar elemento de fijación Befestigungsteil lösen Desapertar fixador Allentare il fissaggio Bevestiging losdraaien Desserrez les fixations		<b>Drill Hole</b> Perforar Bohrloch Fazer furo Praticare un foro Gat boren Percez un trou
	<b>Phillips Screwdriver</b> Destornillador Phillips Kreuzschlitzschraubendreher Chave de fendas Phillips Cacciavite a stella Kruiskopschroevendraaier Tournevis à pointe cruciforme		<b>Adjust</b> Ajustar Einstellen Ajustar Regolare Afstellen Ajuster
	<b>Open-Ended Wrench</b> Llave de boca Gabelschlüssel Chave de bocas Chiave a punte aperte Steeksleutel Clé à fourche		<b>Remove</b> Quitar Entfernen Remover Rimuovere Verwijderen Retirez
	<b>By Hand</b> A mano Von Hand Com a mão A mano Met de hand À la main		<b>Optional</b> Opcional Optional Opcional Opzionale Optie En option
	<b>Hex-Head Wrench</b> Llave de cabeza hexagonal Sechskantschlüssel Chave de cabeça sextavada Chiave esagonale Zeskantsleutel Clé à tête hexagonale		<b>Security Wrench</b> Llave de seguridad Sicherheitsschlüssel Chave de segurança Chiave di sicurezza Veiligheidssleutel Clé de sécurité

## TOOLS REQUIRED FOR INSTALLATION



## PARTS



## INSTALLATION

### Site Preparation



**WARNING:** EXCEEDING WEIGHT CAPACITY CAN RESULT IN SERIOUS PERSONAL INJURY OR DAMAGE TO EQUIPMENT! It is the installer's responsibility to make sure the combined weight of all components attached to the STS1 up to (and including) the display does not exceed 30 lbs (13.6 kg).



**WARNING:** TURNING DISPLAY CAN CAUSE DAMAGE TO SURROUNDING OBJECTS. Make certain location provides enough area for the display to rotate  $\pm 270^\circ$  without being obstructed, or lock display to a lesser rotation before rotating for the first time.




Figure 1

**IMPORTANT ! :** The STS1 is shipped with the display rotation set at the minimum of  $90^\circ$ . Base rotation may be adjusted to  $90^\circ$ ,  $180^\circ$  or  $270^\circ$  and locked if installation location requires it. (See Figure 2)

Display head rotation may be adjusted in any increment between  $0^\circ$  and  $90^\circ$ .

### Setting Rotation Limits

1. Base rotation is factory-set at  $90^\circ$  but may be changed to  $180^\circ$  or  $270^\circ$  to allow necessary rotation. (See Figure 1)
2. Remove and save setscrews from two  $90^\circ$  holes in base using  $3/32$ " hex key (K). (See Figure 2)
3. Determine amount of rotation required in installation.
4. Place setscrews into the appropriate holes ( $180^\circ$  or  $270^\circ$ ) and tighten to secure rotation amount. (See Figure 2)




Figure 2

### Attaching STS1 to Mounting Surface

1. Locate a flat surface (thickness of  $3/4$ " minimum to  $2-1/2$ " maximum) on which to mount the STS1 assembly.
2. Carefully raise STS1 base cover and affix to STS1 column using a piece of tape. (See Figure 3)
3. Mark four mounting hole locations on mounting surface. (See Figure 3)




Figure 3

4. Drill four  $5/16$ " diameter (7.9mm) holes through mounting surface at marks, and an optional  $1-5/8$ " diameter (41.3mm) cable management hole. (See Figure 3)

5. Attach STS1 to mounting surface using 5/32" hex key (L) and four 1/4-20 x 3" buttonhead cap screws (E), four flat 1/4" flat washers (G), four 1/4" fender washer (H), and four 1/4" Nylock nuts (F). (See Figure 4)
6. Lower STS1 base cover.




Figure 4

## Attaching Display



**WARNING:** IMPROPER INSTALLATION CAN LEAD TO DISPLAY FALLING CAUSING SERIOUS PERSONAL INJURY OR DAMAGE TO EQUIPMENT! Using screws of improper size may damage your display. Properly sized screws will easily and completely thread into display mounting holes. If spacers are required, be sure to use longer screws of the same diameter.

1. Select correct screws, spacers (if necessary) from the hardware bag (J) and attach STS1 to back of display. (See Figure 5)




Figure 5

## Cable Management

1. Run power cables from display to the back of the STS1.
2. Lay power cables down back and through bottom of STS1, and through mounting surface.
3. Add wire cover (B) to back of STS1 by sliding it into the STS1 through the top. (See Figure 6)
4. Add top cap (C) to top of STS1. (See Figure 6)
5. Add base cable plug (D) to STS1 base. (See Figure 6)




Figure 6

## Adjustments

### Rotating Display

1. The display may be rotated up to 90° on the STS1 head by using the 5/32" hex key (L) to loosen the fastener, rotating the head in either direction, and tightening the fastener. (See Figure 7)




Figure 7

### Display Roll, Pitch, Yaw Tension

The display roll, pitch and yaw tension can be adjusted either using the tension adjustment knob, or the hex fastener on the head assembly.

#### • Tension Adjustment Knob

1. Turn the tension adjustment knob counter-clockwise to decrease tension. (See Figure 8)
2. Adjust STS1 head and display as required.
3. Turn adjustment knob clockwise to increase tension.




Figure 8

#### • Head Assembly Hex Fastener

4. Loosen the head assembly hex fastener using the 5/32" hex key (L) to decrease tension. (See Figure 8)
5. Adjust STS1 head as required.
6. Tighten head assembly hex fastener to increase tension.

### Raising/Lowering Display

1. Loosen, but do not remove, two Phillips head screws on back of STS1 assembly. (See Figure 9)
2. Adjust display and head assembly to necessary height.
3. Tighten two Phillips head screws on back of STS1 assembly. (See Figure 9)




Figure 9



Our Mounts. **Your Vision.**

Chief Manufacturing, a products division  
of Milestone AV Technologies

8804-002015 Rev01  
©2010 Milestone AV Technologies, a  
Duchossois Group Company  
[www.chiefmfg.com](http://www.chiefmfg.com)  
07/10

**USA/International**

**A** 8401 Eagle Creek Parkway, Savage, MN 55378  
**P** 800.582.6480 / 952.894.6280  
**F** 877.894.6918 / 952.894.6918

**Europe**

**A** Fellenoord 130 5611 ZB EINDHOVEN, The Netherlands  
**P** +31 (0)40 2668620  
**F** +31 (0)40 2668615

**Asia Pacific**

**A** Office No. 1 on 12/F, Shatin Galleria  
18-24 Shan Mei Street  
Fotan, Shatin, Hong Kong  
**P** 852 2145 4099  
**F** 852 2145 4477

